

CPT Cone Maintenance Chart

	Before every push	After every push	Periodic daily checks	Before storage	Annually
Use calipers or no-go gauge to measure wear surfaces	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Check o-rings	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Clean tip, sleeve, and pore pressure filter	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Check pore pressure filter and fluid. Replace if necessary.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Verify connections are tight	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Cone calibration					<input checked="" type="checkbox"/>

= Required

= Optional